

## TYPICAL RADIATION PATTERN at 2442.5 MHz



### TYPICAL GAIN DIAGRAM vs FREQUENCY



SDC-2.4-15

UHF Base Station Cavity Backed Antenna 2400 - 2485 MHz W-LAN



Installation Manual

# DESCRIPTION

Directional base station antenna for outdoor use working on 2400-2485 MHz conceived for WLAN system. The radiant element, made of brass, is mounted into a metal case and sealed with a thermoplastic cover. It's supplied with a stainless steel bracket for an easy installation on the mast in vertical or horizontal polarization.

# (SPECIFICATIONS)

### **Electrical Data**

Type : Cavity Backed

Frequency Range : 2400-2485 MHz for W-LAN band

Impedance : 50  $\Omega$  Unbalanced

Polarization : Linear Vertical or Horizontal

Gain : 15 dBi

Half Power Beam Width

E-plane : 33° at 2442.5 MHz H-plane : 27° at 2442.5 MHz

Downtilt : Mechanical: Bracket tilt function

Front to back ratio :  $\geq 25 \text{ dB}$  V.S.W.R. in Bandwidth :  $\leq 1.6:1$ 

Max Power : 20 Watts (CW) at 50° C

Lightning protection : DC-ground Connector type : SMA-female

### **Mechanical Data**

Housing Material : Case: aluminium grey RAL 9007; Antenna element: brass;

Bracket and hardware: stainless steel

Radome Material : Light grey RAL 7035 thermoplastic UV stabilized

Wind load / Resistance : 104 N at 150 Km/h / 160 Km/h


Wind surface : 0.06 m<sup>2</sup>

Dimensions (approx.) :  $\emptyset$  275 x 80 mm without bracket


Weight (approx.) : 720 c

Mounting : Mast Ø 35-50 mm with clamp included Wall with mounting screws (not included)

#### TYPICAL S.W.R. RESPONSE



# **MOUNTING INSTRUCTIONS**



#### Polarization:

The antenna polarization is shown on the label sticked on the rear side of the antenna (1).


Usually the vertical polarization is used for the networks access and the horizontal polarization for point to point links.

## Weather proofing:

The SMA connector is weather proofed thanks to the supplied heat shrinking tube. Make use of a hot air gun to shrink the shrinking tube.

## Important:

The drainage holes must be at the bottom of the antenna.



Mounting on the wall with screws (not included)